



Vincotech

flow PACK 0B

Output Inverter Application

600 V / 6 A

General conditions

3phase SPWM

$V_{GEon} = 15\text{ V}$

$V_{GEoff} = -15\text{ V}$


$R_{gon} = 64\ \Omega$

$R_{goff} = 64\ \Omega$

figure 1. IGBT

Typical average static loss as a function of output current

$P_{loss} = f(I_{out})$




At
 $T_j = 125\ \text{°C}$
 $Mi \cdot \cos\phi$ from -1 to 1 in steps of 0,2

figure 2. FWD

Typical average static loss as a function of output current

$P_{loss} = f(I_{out})$




At
 $T_j = 125\ \text{°C}$
 $Mi \cdot \cos\phi$ from -1 to 1 in steps of 0,2

figure 3. IGBT

Typical average switching loss as a function of output current

$P_{loss} = f(I_{out})$




At
 $T_j = 125\ \text{°C}$
DC-link = 400 V
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

figure 4. FWD

Typical average switching loss as a function of output current

$P_{loss} = f(I_{out})$




At
 $T_j = 125\ \text{°C}$
DC-link = 400 V
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2



figure 5. Phase


Typical available 50Hz output current as a function $Mi \cdot \cos \varphi$ $I_{out} = f(Mi \cdot \cos \varphi)$



At
 $T_j = 125^\circ\text{C}$
 DC-link = 400 V
 $f_{sw} = 4$ kHz
 T_s from 60°C to 100°C in steps of 5°C

figure 6. Phase


Typical available 50Hz output current as a function of switching frequency $I_{out} = f(f_{sw})$



At
 $T_j = 125^\circ\text{C}$
 DC-link = 400 V
 $Mi \cdot \cos \varphi = 0,8$
 T_s from 60°C to 100°C in steps of 5°C

figure 7. Phase


Typical available 50Hz output current as a function of $Mi \cdot \cos \varphi$ and switching frequency $I_{out} = f(f_{sw}, Mi \cdot \cos \varphi)$



At
 $T_j = 125^\circ\text{C}$
 DC-link = 400 V
 $T_s = 80^\circ\text{C}$

figure 8. Phase

Typical available 0Hz output current as a function of switching frequency $I_{outpeak} = f(f_{sw})$



At
 $T_j = 125^\circ\text{C}$
 DC-link = 400 V
 T_s from 60°C to 100°C in steps of 5°C
 $Mi = 0$



Vincotech


flow PACK 0B

Output Inverter Application

600 V / 6 A

figure 9. Inverter


Typical available peak output power as a function of heatsink temperature
 $P_{out} = f(T_s)$



At
 $T_j = 125$ °C
 DC-link = 400 V
 $M_i = 1$
 $\cos \varphi = 0,80$
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

figure 10. Inverter


Typical efficiency as a function of output power
efficiency = $f(P_{out})$



At
 $T_j = 125$ °C
 DC-link = 400 V
 $M_i = 1$
 $\cos \varphi = 0,80$
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

figure 11. Inverter

Typical available overload factor as a function of motor power and switching frequency
 $P_{peak} / P_{nom} = f(P_{nom}, f_{sw})$



At
 $T_j = 125$ °C
 DC-link = 400 V
 $M_i = 1$
 $\cos \varphi = 0,8$
 f_{sw} from 1 kHz to 16kHz in steps of factor 2
 $T_s = 80$ °C
 Motor eff = 0,85