


General conditions

3phase SPWM	
$V_{G\text{Eon}}$	= 15 V
$V_{G\text{Eoff}}$	= -15 V
$R_{g\text{on}}$	= 32 Ω
$R_{g\text{off}}$	= 32 Ω

Figure 1
IGBT
Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$



At

$$T_j = 126 \quad ^\circ\text{C}$$

Mi*cosphi from -1 to 1 in steps of 0,2

Figure 2
FWD
Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$



At

$$T_j = 126 \quad ^\circ\text{C}$$

Mi*cosphi from -1 to 1 in steps of 0,2

Figure 3
IGBT
Typical average switching loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$


At


$$T_j = 126 \quad ^\circ\text{C}$$

$$\text{DC link} = 400 \quad \text{V}$$

fsw from 2 kHz to 16 kHz in steps of factor 2

Figure 4
FWD
Typical average switching loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$



At

$$T_j = 126 \quad ^\circ\text{C}$$

$$\text{DC link} = 400 \quad \text{V}$$


fsw from 2 kHz to 16 kHz in steps of factor 2

Figure 5 Phase
Typical available 50Hz output current as a function $M_i \cos \phi$
 $I_{out} = f(M_i \cos \phi)$




At
 $T_j = 126 \text{ } ^\circ\text{C}$
DC link = 400 V
 $f_{sw} = 4 \text{ kHz}$
 T_h from 60 °C to 100 °C in steps of 5 °C

Figure 6 Phase
Typical available 50Hz output current as a function of switching frequency
 $I_{out} = f(f_{sw})$




At
 $T_j = 126 \text{ } ^\circ\text{C}$
DC link = 400 V
 $M_i \cos \phi = 0,8$
 T_h from 60 °C to 100 °C in steps of 5 °C

Figure 7 Phase
Typical available 50Hz output current as a function of $M_i \cos \phi$ and switching frequency
 $I_{out} = f(f_{sw}, M_i \cos \phi)$



At
 $T_j = 126 \text{ } ^\circ\text{C}$
DC link = 400 V
 $T_h = 80 \text{ } ^\circ\text{C}$

Figure 8 Phase
Typical available 0Hz output current as a function of switching frequency
 $I_{outpeak} = f(f_{sw})$



At
 $T_j = 126 \text{ } ^\circ\text{C}$
DC link = 400 V
 T_h from 60 °C to 100 °C in steps of 5 °C
 $M_i = 0$



Vincotech

flowPIM0+PFC 2nd

Output Inverter Application


600 V / 10 A

10-F006PPA010SB-M683B

10-F006PPA010SB-M683BY

datasheet

Figure 9 Inverter
Typical available peak output power as a function of heatsink temperature
 $P_{out}=f(T_h)$

**At** $T_j = 126 \text{ } ^\circ\text{C}$


DC link = 400 V

Mi = 1

 $\cos \varphi = 0,80$

fsw from 2 kHz to 16 kHz in steps of factor 2

Figure 10 Inverter
Typical efficiency as a function of output power
efficiency=f(P_{out})

**At** $T_j = 126 \text{ } ^\circ\text{C}$


DC link = 400 V

Mi = 1

 $\cos \varphi = 0,80$

fsw from 2 kHz to 16 kHz in steps of factor 2

Figure 11 Inverter
Typical available overload factor as a function of motor power and switching frequency
 $P_{peak} / P_{nom}=f(P_{nom}, f_{sw})$

**At** $T_j = 126 \text{ } ^\circ\text{C}$

DC link = 400 V

Mi = 1

 $\cos \varphi = 0,8$

fsw from 1 kHz to 16 kHz in steps of factor 2

 $T_h = 80 \text{ } ^\circ\text{C}$


Motor eff = 0,85

General conditions
Boost PFC

$$\begin{aligned}V_{G\text{On}} &= 10 \text{ V} \\V_{G\text{Off}} &= 0 \text{ V} \\R_{\text{gon}} &= 8 \Omega \\R_{\text{goff}} &= 8 \Omega \\V_{\text{in}} &= V_{\text{inp}k} * \sin \omega t\end{aligned}$$

Figure 1
MOSFET
Typical average static loss as a function of input current

$$P_{\text{loss}} = f(I_{\text{in}})$$



At

$$T_j = 125 \text{ } ^\circ\text{C}$$

Vinpk / Vout from 0,1 to 1 in steps of 0,1

Figure 2
FWD
Typical average static loss as a function of input current

$$P_{\text{loss}} = f(I_{\text{in}})$$



At

$$T_j = 125 \text{ } ^\circ\text{C}$$

Vinpk / Vout from 0,1 to 1 in steps of 0,1

Figure 3
MOSFET
**Typical average switching loss
as a function of input current**

$$P_{\text{loss}} = f(I_{\text{in}})$$


At


$$T_j = 125 \text{ } ^\circ\text{C}$$

$$\text{DC link} = 400 \text{ V}$$

fsw from 20 kHz to 160 kHz in steps of factor 2

Figure 4
FWD
**Typical average switching loss
as a function of input current**

$$P_{\text{loss}} = f(I_{\text{in}})$$


At


$$T_j = 125 \text{ } ^\circ\text{C}$$

$$\text{DC link} = 400 \text{ V}$$

fsw from 20 kHz to 160 kHz in steps of factor 2

Figure 5
PFC
**Typical available input current
as a function of $V_{\text{inpk}} / V_{\text{out}}$**


$$I_{\text{in}} = f(V_{\text{inpk}} / V_{\text{out}})$$


At
 $T_j = 125 \text{ } ^\circ\text{C}$
 $\text{DC link} = 400 \text{ V}$
 $f_{\text{sw}} = 20 \text{ kHz}$

Th from 60 °C to 100 °C in steps of 5 °C

Figure 6
PFC
**Typical available input current
as a function of switching frequency**


$$I_{\text{in}} = f(f_{\text{sw}})$$


At
 $T_j = 125 \text{ } ^\circ\text{C}$
 $\text{DC link} = 400 \text{ V}$
 $V_{\text{inpk}} / V_{\text{out}} = 0,8$


Th from 60 °C to 100 °C in steps of 5 °C

Figure 7
PFC
**Typical available input current as a function of
of $V_{\text{inpk}} / V_{\text{out}}$ and switching frequency**

$$I_{\text{in}} = f(f_{\text{sw}}, V_{\text{inpk}} / V_{\text{out}})$$



At
 $T_j = 125 \text{ } ^\circ\text{C}$
 $\text{DC link} = 400 \text{ V}$
 $T_h = 80 \text{ } ^\circ\text{C}$
Figure 8
PFC
**Typical available input current
as a function of switching frequency**

$$I_{\text{in}} = f(f_{\text{sw}})$$


At
 $T_j = 125 \text{ } ^\circ\text{C}$
 $\text{DC link} = 400 \text{ V}$
 $V_{\text{inpk}} / V_{\text{out}} = 0,4$


Th from 60 °C to 100 °C in steps of 5 °C

Figure 9 PFC
Typical available electric input power as a function of heatsink temperature
 $P_{in} = f(T_h)$




At
 $T_j = 125 \text{ } ^\circ\text{C}$
DC link = 400 V
 $V_{inpk}/V_{out} = 0,8 \text{ kHz}$
fsw from 20 kHz to 160 kHz in steps of factor 2

Figure 11 PFC
Typical available electric input power as a function of heatsink temperature
 $P_{in} = f(T_h)$




At
 $T_j = 125 \text{ } ^\circ\text{C}$
DC link = 400 V
 $V_{inpk}/V_{out} = 0,4$
fsw from 20 kHz to 160 kHz in steps of factor 2

Figure 10 PFC
Typical efficiency as a function of input power
efficiency = $f(P_{in})$




At
 $T_j = 125 \text{ } ^\circ\text{C}$
DC link = 400 V
 $V_{inpk}/V_{out} = 0,8 \text{ kHz}$
fsw from 20 kHz to 160 kHz in steps of factor 2

Figure 12 PFC
Typical efficiency as a function of input power
efficiency = $f(P_{in})$




At
 $T_j = 125 \text{ } ^\circ\text{C}$
DC link = 400 V
 $V_{inpk}/V_{out} = 0,4$
fsw from 20 kHz to 160 kHz in steps of factor 2

Figure 13 Rectifier
Typical average static loss as a function of input current
 $P_{\text{loss}} = f(I_{\text{in}})$




At
 $T_j = 125 \text{ } ^\circ\text{C}$

Figure 15 Overall
Typical efficiency as a function of input power
 $\text{efficiency} = f(P_{\text{in}})$




At
 $T_j = 125 \text{ } ^\circ\text{C}$
DC link = 400 V
 $V_{\text{inpk}}/V_{\text{out}} = 0.8$ kHz
fsw from 20 kHz to 160 kHz in steps of factor 2

Figure 14 Rectifier Bridge
Typical efficiency as a function of input power
 $\text{efficiency} = f(P_{\text{in}})$



At
 $T_j = 125 \text{ } ^\circ\text{C}$

Figure 16 Overall
Typical efficiency as a function of input power
 $\text{efficiency} = f(P_{\text{in}})$



At
 $T_j = 125 \text{ } ^\circ\text{C}$
DC link = 400 V
 $V_{\text{inpk}}/V_{\text{out}} = 0.4$ kHz
fsw from 20 kHz to 160 kHz in steps of factor 2