


## General conditions

|                    |         |
|--------------------|---------|
| <b>3phase SPWM</b> |         |
| $V_{G\text{eon}}$  | = 15 V  |
| $V_{G\text{off}}$  | = -15 V |
| $R_{g\text{on}}$   | = 16 Ω  |
| $R_{g\text{off}}$  | = 16 Ω  |

Figure 1

IGBT

Typical average static loss as a function of output current  
 $P_{\text{loss}} = f(I_{\text{out}})$



At


 $T_j = 150^\circ\text{C}$ 

Mi\*cosphi from -1 to 1 in steps of 0,2

Figure 2

FWD

Typical average static loss as a function of output current  
 $P_{\text{loss}} = f(I_{\text{out}})$



At


 $T_j = 150^\circ\text{C}$ 

Mi\*cosphi from -1 to 1 in steps of 0,2

Figure 3

IGBT

Typical average switching loss as a function of output current  
 $P_{\text{loss}} = f(I_{\text{out}})$



At

 $T_j = 150^\circ\text{C}$ 


DC link = 600 V

 $f_{\text{sw}}$  from 2 kHz to 16 kHz in steps of factor 2

Figure 4

FWD

Typical average switching loss as a function of output current  
 $P_{\text{loss}} = f(I_{\text{out}})$




At


 $T_j = 150^\circ\text{C}$ 

DC link = 600 V


 $f_{\text{sw}}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 5****At**


$T_j = 150 \text{ } ^\circ\text{C}$   
 DC link = 600 V  
 $f_{sw} = 4 \text{ kHz}$   
 $T_h$  from 60 °C to 100 °C in steps of 5 °C

**Figure 7****At**

$T_j = 150 \text{ } ^\circ\text{C}$   
 DC link = 600 V  
 $T_h = 80 \text{ } ^\circ\text{C}$

**Figure 6****At**

$T_j = 150 \text{ } ^\circ\text{C}$   
 DC link = 600 V  
 $M_i \cos \varphi : 0,8$   
 $T_h$  from 60 °C to 100 °C in steps of 5 °C

**Figure 8****At**


$T_j = 150 \text{ } ^\circ\text{C}$   
 DC link = 600 V  
 $T_h$  from 60 °C to 100 °C in steps of 5 °C  
 $M_i = 0$

**Figure 9**

Inverter

**Typical available peak output power as a function of heatsink temperature**

$$P_{\text{out}} = f(T_h)$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC link} = 600 \text{ V}$$

$$M_i = 1$$

$$\cos \varphi = 0,80$$


$f_{\text{sw}}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 10**

Inverter

**Typical efficiency as a function of output power**

$$\text{efficiency} = f(P_{\text{out}})$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC link} = 600 \text{ V}$$

$$M_i = 1$$


$$\cos \varphi = 0,80$$

$f_{\text{sw}}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 11**

Inverter

**Typical available overload factor as a function of motor power and switching frequency**  $P_{\text{peak}} / P_{\text{nom}} = f(P_{\text{nom}}, f_{\text{sw}})$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC link} = 600 \text{ V}$$

$$M_i = 1$$

$$\cos \varphi = 0,8$$

$f_{\text{sw}}$  from 1 kHz to 16 kHz in steps of factor 2

$$T_h = 80 \text{ } ^\circ\text{C}$$

$$\text{Motor eff} = 0,85$$