


flowNPC0 NPC Application 600V/50A

Figure 20. Boost IGBT+FWD

Typical available output current as a function of phase displacement

$I_{out}=f(\varphi)$




Conditions: $T_j = T_{jmax}-25 \text{ }^\circ\text{C}$ $f_{sw} = 20 \text{ kHz}$
 DC link= 700 V
 parameter: Heatsink temp.
 Th from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 21. Boost IGBT+FWD

Typical available output current as a function of switching frequency

$I_{out}=f(f_{sw})$




Conditions: $T_j = T_{jmax}-25 \text{ }^\circ\text{C}$ $\varphi = 90^\circ$
 DC link= 700 V
 parameter: Heatsink temp.
 Th from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 22. Boost IGBT+FWD

Typical available 50Hz output current as a function of fsw and phase displacement

$I_{out}=f(f_{sw},\varphi)$




Conditions: $T_j = T_{jmax}-25 \text{ }^\circ\text{C}$
 DC link= 700 V
 $T_h = 80 \text{ }^\circ\text{C}$

flowNPC0 NPC Application 600V/50A

Figure 23. per MODULE

Typical available output current as a function of heat sink temperature

$I_{out}=f(T_h)$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
DC link= 700 V
 $\varphi = 0^\circ$
parameter: Switching freq.
fsw from 2 kHz to 128 kHz
in steps of factor 2

Figure 24. per MODULE

Typical available output current as a function of phase displacement

$I_{out}=f(\varphi)$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
DC link= 700 V
fsw= 20 kHz
parameter: Heatsink temp.
Th from 50 °C to 100 °C
in 10 °C steps

Figure 25. per MODULE

Typical available output current as a function of switching frequency

$I_{out}=f(f_{sw})$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$ $\varphi = 0^\circ$
DC link= 700 V
parameter: Heatsink temp.
Th from 50 °C to 100 °C
in 10 °C steps

Figure 26. per MODULE

Typical available 50Hz output current as a function of fsw and phase displacement

$I_{out}=f(f_{sw},\varphi)$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
DC link= 700 V
 $T_h = 80 \text{ } ^\circ\text{C}$

flowNPC0 NPC Application 600V/50A

Figure 27. per MODULE


Typical efficiency as a function of output power



Conditions: $T_j = 150$ °C
 $f_{sw} = 20$ kHz
 DC link = 700 V
 parameter: phase displacement φ from 0° to 180° in steps of 30°

Figure 28. per MODULE


Typical efficiency as a function of output power



Conditions: $T_j = 150$ °C $\varphi = 0^\circ$
 DC link = 700 V
 parameter: Switching freq. f_{sw} from 2 kHz to 128 kHz in steps of factor 2

Figure 29. per MODULE

Typical available output power as a function of heat sink temperature



Conditions: $T_j = T_{jmax}-25$ °C
 DC link = 700 V
 $\varphi = 0$ °
 parameter: Switching freq. f_{sw} from 2 kHz to 128 kHz in steps of factor 2





Figure 30. per MODULE

Typical loss distribution as a function of output current

$$P_{out}=f(T_h)$$




Conditions:

T_j =	150	°C
f_{sw} =	20	kHz
DC link=	700	V
φ =	0°	

Figure 31. per MODULE

Typical relativ loss distribution as a function of output current

$$P_{out}=f(T_h)$$



Conditions:

T_j =	150	°C
f_{sw} =	20	kHz
DC link=	700	V
φ =	0°	