

**flowNPC 0**
**NPC Application**
**600V/30A**


<b>BUCK</b>	
$V_{GEon}$	= 10 V
$V_{GOff}$	= 0 V
$R_{gon}$	= 8 Ω
$R_{goff}$	= 8 Ω

**General conditions**
**Vout= 230 VAC**

<b>BOOST</b>	
$V_{GEon}$	= 15 V
$V_{GOff}$	= 0 V
$R_{gon}$	= 8 Ω
$R_{goff}$	= 8 Ω

**Figure 1.**
**Buck MOSFET**
**Typical average static loss as a function of output current  $I_{oRMS}$** 


$P_{loss}=f(I_{out})$



Conditions:  $T_j = 125^\circ C$   
parameter:  $\phi$  from  $0^\circ$  to  $180^\circ$   
in 12 steps

**Figure 3.**
**Buck MOSFET**
**Typical average static loss as a function of phase displacement  $\phi$** 


$P_{loss}=f(\phi)$



Conditions:  $T_j = 125^\circ C$   
parameter:  $I_{oRMS}$  from 2,83 A to 42 A  
in steps of 6 A

**Figure 2.**
**Buck FWD**
**Typical average static loss as a function of output current  $I_{oRMS}$** 


$P_{loss}=f(I_{out})$



Conditions:  $T_j = 125^\circ C$   
parameter:  $\phi$  from  $0^\circ$  to  $180^\circ$   
in 12 steps

**Figure 4.**
**Buck FWD**
**Typical average static loss as a function of phase displacement  $\phi$** 


$P_{loss}=f(\phi)$



Conditions:  $T_j = 125^\circ C$   
parameter:  $I_{oRMS}$  from 2,83 A to 42 A  
in steps of 6 A


**flowNPC 0**
**NPC Application**
**600V/30A**

**Figure 5.**  
**Typical average switching loss as a function of phase displacement  $\phi$**   
 $P_{loss}=f(\phi)$




Conditions:  $T_j=125^\circ\text{C}$   
 $f_{sw}=20\text{ kHz}$   
DC link= 700 V  
parameter:  $I_{oRMS}$  from 2,83 A to 42 A  
in steps of 6 A

**Figure 6.**  
**Typical average switching loss as a function of phase displacement  $\phi$**   
 $P_{loss}=f(\phi)$




Conditions:  $T_j=125^\circ\text{C}$   
 $f_{sw}=20\text{ kHz}$   
DC link= 700 V  
parameter:  $I_{oRMS}$  from 2,83 A to 42 A  
in steps of 6 A

**Figure 7.**  
**Typical total loss as a function of phase displacement  $\phi$  and output current  $I_{oRMS}$**   
 $P_{loss}=f(I_{oRMS};\phi)$



Conditions:  $T_j=125^\circ\text{C}$   
DC link= 700 V  
 $f_{sw}=20\text{ kHz}$


**Figure 8.**  
**Typical total loss as a function of phase displacement  $\phi$  and output current  $I_{oRMS}$**   
 $P_{loss}=f(I_{oRMS};\phi)$



Conditions:  $T_j=125^\circ\text{C}$   
DC link= 700 V  
 $f_{sw}=20\text{ kHz}$


**flowNPC 0**
**NPC Application**
**600V/30A**

**Figure 9.** for Buck MOSFET+FWD  
Typical available output current as a function of phase displacement  $\varphi$




Conditions:  $T_j = T_{jmax}-25 \ ^\circ\text{C}$        $f_{sw} = 20 \text{ kHz}$   
DC link = 700 V  
parameter: Heatsink temp.  
 $T_h$  from 50  $^\circ\text{C}$  to 100  $^\circ\text{C}$   
in 10  $^\circ\text{C}$  steps

**Figure 10.** for Buck MOSFET+FWD  
Typical available output current as a function of switching frequency  $f_{sw}$



Conditions:  $T_j = T_{jmax}-25 \ ^\circ\text{C}$        $\varphi = 0^\circ$   
DC link = 700 V  
parameter: Heatsink temp.  
 $T_h$  from 50  $^\circ\text{C}$  to 100  $^\circ\text{C}$   
in 10  $^\circ\text{C}$  steps


**Figure 11.** for Buck IGBT+FWD  
Typical available 50Hz output current as a function of  $f_{sw}$  and phase displacement  $\varphi$



Conditions:  $T_j = T_{jmax}-25 \ ^\circ\text{C}$   
DC link = 700 V  
 $T_h = 80 \ ^\circ\text{C}$

**flowNPC 0**
**NPC Application**
**600V/30A**
**Figure 12.**
**Boost IGBT**
**Typical average static loss as a function of output current**


$$P_{\text{loss}} = f(I_{\text{out}})$$



Conditions:  $T_j = 125^\circ\text{C}$   
parameter:  $\varphi$  from  $0^\circ$  to  $180^\circ$   
in 12 steps

**Figure 14.**
**Boost IGBT**
**Typical average static loss as a function of phase displacement**


$$P_{\text{loss}} = f(\varphi)$$



Conditions:  $T_j = 125^\circ\text{C}$   
parameter:  $I_{\text{outRMS}}$  from 3 A to 42 A  
in steps of 6 A

**Figure 13.**
**Boost FWD**
**Typical average static loss as a function of output current**


$$P_{\text{loss}} = f(I_{\text{out}})$$



Conditions:  $T_j = 125^\circ\text{C}$   
parameter:  $\varphi$  from  $0^\circ$  to  $180^\circ$   
in 12 steps

**Figure 15.**
**Boost FWD**
**Typical average static loss as a function of phase displacement**

$$P_{\text{loss}} = f(\varphi)$$



Conditions:  $T_j = 125^\circ\text{C}$   
parameter:  $I_{\text{outRMS}}$  from 3 A to 42 A  
in steps of 6 A

flowNPC 0


**NPC Application**

600V/30A

**Figure 16.****Boost IGBT**

**Typical average switching loss as a function of phase displacement**

$$P_{loss} = f(\phi)$$




Conditions:  $T_j = 125^\circ\text{C}$        $f_{sw} = 20 \text{ kHz}$   
 DC link = 700 V  
 parameter:  $I_{oRMS}$  from 3 A to 42 A  
 in steps of 6 A

**Figure 18.****Boost IGBT**

**Typical total loss as a function of phase displacement and  $I_{outRMS}$**

$$P_{loss} = f(I_{oRMS}; \phi)$$




Conditions:  $T_j = 125^\circ\text{C}$   
 DC link = 700 V  
 $f_{sw} = 20 \text{ kHz}$

**Figure 17.****Boost FWD**

**Typical average switching loss as a function of phase displacement**

$$P_{loss} = f(\phi)$$




Conditions:  $T_j = 125^\circ\text{C}$        $f_{sw} = 20 \text{ kHz}$   
 DC link = 700 V  
 parameter:  $I_{oRMS}$  from 3 A to 42 A  
 in steps of 6 A

**Figure 19.****Boost FWD**

**Typical total loss as a function of phase displacement and  $I_{outRMS}$**


$$P_{loss} = f(I_{oRMS}; \phi)$$



Conditions:  $T_j = 125^\circ\text{C}$   
 DC link = 700 V  
 $f_{sw} = 20 \text{ kHz}$

**flowNPC 0**
**NPC Application**
**600V/30A**
**Figure 20.**
**Boost IGBT+FWD**
**Typical available output current as a function  
of phase displacement**


$I_{out}=f(\phi)$


**Conditions:**  $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$        $f_{sw} = 20 \text{ kHz}$   
DC link = 700 V

**parameter:** Heatsink temp.  
Th from 50 °C to 100 °C  
in 10 °C steps

**Figure 21.**
**Boost IGBT+FWD**
**Typical available output current  
as a function of switching frequency**


$I_{out}=f(f_{sw})$


**Conditions:**  $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$        $\varphi = 90^\circ$   
DC link = 700 V


**parameter:** Heatsink temp.  
Th from 50 °C to 100 °C  
in 10 °C steps

**Figure 22.**
**Boost IGBT+FWD**
**Typical available 50Hz output current as a function of  
fsw and phase displacement**

$I_{out}=f(f_{sw}, \phi)$



**Conditions:**  $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$   
DC link = 700 V  
 $T_h = 80 \text{ } ^\circ\text{C}$

**flowNPC 0**
**NPC Application**
**600V/30A**
**Figure 23.** per MODULE

**Typical available output current as a function of heat sink temperature**

Conditions:  $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$   
DC link = 700 V  
 $\phi = 0 \text{ } ^\circ$ 


parameter: Switching freq.  
fsw from 2 kHz to 128 kHz  
in steps of factor 2

**Figure 24.** per MODULE

**Typical available output current as a function of phase displacement**

Conditions:  $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$   
DC link = 700 V  
 $f_{sw} = 20 \text{ kHz}$ 


parameter: Heatsink temp.  
Th from 50 °C to 100 °C  
in 10 °C steps

**Figure 25.** per MODULE

**Typical available output current as a function of switching frequency**

Conditions:  $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$   
DC link = 700 V  
 $\phi = 0 \text{ } ^\circ$ 

parameter: Heatsink temp.  
Th from 50 °C to 100 °C  
in 10 °C steps


**Figure 26.** per MODULE

**Typical available 50Hz output current as a function of fsw and phase displacement**

Conditions:  $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$   
DC link = 700 V  
 $T_h = 80 \text{ } ^\circ\text{C}$

**flowNPC 0**
**NPC Application**
**600V/30A**
**Figure 27.** per MODULE

**Typical efficiency as a function of output power**

$\eta=f(P_{out})$



Conditions:  $T_j=125^\circ\text{C}$   
 $f_{sw}=20\text{ kHz}$   
DC link= 700 V

parameter: phase displacement  
 $\phi$  from 0° to 180°  
in steps of 30°

**Figure 28.** per MODULE

**Typical efficiency as a function of output power**

$\eta=f(P_{out})$



Conditions:  $T_j=125^\circ\text{C}$   
DC link= 700 V  
 $\phi=0^\circ$ 

parameter: Switching freq.  
fsw from 2 kHz to 128 kHz  
in steps of factor 2

**Figure 29.** per MODULE

**Typical available output power as a function of heat sink temperature**


$P_{out}=f(T_h)$


Conditions:  $T_j=T_{jmax}-25^\circ\text{C}$   
DC link= 700 V  
 $\phi=0^\circ$ 

parameter: Switching freq.  
fsw from 2 kHz to 128 kHz  
in steps of factor 2

**flowNPC 0**
**NPC Application**
**600V/30A**


**Figure 30.** per MODULE  
**Typical loss distribution as a function of output current**




Conditions:

$T_j =$	125	$^{\circ}\text{C}$
$f_{sw} =$	20	kHz
DC link =	700	V
$\phi =$	0	$^{\circ}$

**Figure 31.**  
**Typical application**



**Figure 32.** per MODULE  
**Typical relativ loss distribution as a function of output current**



Conditions:

$T_j =$	125	$^{\circ}\text{C}$
$f_{sw} =$	20	kHz
DC link =	700	V
$\phi =$	0	$^{\circ}$