

flowNPC1 **NPC Application** 600V/41mΩ

General conditions


BUCK	
V_{GEon}	= 10 V
V_{GEoff}	= 0 V
R_{gon}	= 4 Ω
R_{goff}	= 4 Ω

$V_{out} = 230 \text{ VAC}$

BOOST	
V_{GEon}	= 10 V
V_{GEoff}	= 0 V
R_{gon}	= 4 Ω
R_{goff}	= 4 Ω

Figure 1. Buck MOSFET


Typical average static loss as a function of output current I_{oRMS}



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: ϕ from 0° to 180°
in 12 steps

Figure 2. Buck FWD


Typical average static loss as a function of output current I_{oRMS}



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: ϕ from 0° to 180°
in 12 steps

Figure 3. Buck MOSFET


Typical average static loss as a function of phase displacement ϕ



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: I_{oRMS} from 2 A to 30 A
in steps of 4 A

Figure 4. Buck FWD


Typical average static loss as a function of phase displacement ϕ



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: I_{oRMS} from 2 A to 30 A
in steps of 4 A


flowNPC1 NPC Application 600V/41mΩ

Figure 5. Buck MOSFET




Conditions: $T_j = 125$ °C
 $f_{sw} = 50$ kHz
 DC link = 700 V
 parameter: I_{ORMS} from 2 A to 30 A
 in steps of 4 A

Figure 6. Buck FWD




Conditions: $T_j = 125$ °C
 $f_{sw} = 50$ kHz
 DC link = 700 V
 parameter: I_{ORMS} from 2 A to 30 A
 in steps of 4 A

Figure 7. Buck MOSFET



Conditions: $T_j = 125$ °C
 DC link = 700 V
 $f_{sw} = 50$ kHz

Figure 8. Buck FWD




Conditions: $T_j = 125$ °C
 DC link = 700 V
 $f_{sw} = 50$ kHz

flowNPC1 NPC Application 600V/41mΩ

Figure 9. for Buck MOSFET+FWD


Typical available output current as a function of phase displacement ϕ



Conditions: $T_j = T_{jmax} - 25 \text{ }^\circ\text{C}$ $f_{sw} = 50 \text{ kHz}$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 10. for Buck MOSFET+FWD


Typical available output current as a function of switching frequency f_{sw}



Conditions: $T_j = T_{jmax} - 25 \text{ }^\circ\text{C}$ $\phi = 0^\circ$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 11. for Buck MOSFET+FWD

Typical available 50Hz output current as a function of f_{sw} and phase displacement ϕ



Conditions: $T_j = T_{jmax} - 25 \text{ }^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ }^\circ\text{C}$

flowNPC1
NPC Application
600V/41mΩ
Figure 12. Boost MOSFET
Typical average static loss as a function of output current

$$P_{loss} = f(I_{out})$$



 Conditions: $T_j = 125 \text{ } ^\circ\text{C}$
 parameter: φ from 0° to 180°
 in 12 steps

Figure 13. Boost FWD
Typical average static loss as a function of output current

$$P_{loss} = f(I_{out})$$



 Conditions: $T_j = 125 \text{ } ^\circ\text{C}$
 parameter: φ from 0° to 180°
 in 12 steps

Figure 14. Boost MOSFET
Typical average static loss as a function of phase displacement

$$P_{loss} = f(\varphi)$$




 Conditions: $T_j = 125 \text{ } ^\circ\text{C}$
 parameter: I_{oRMS} from 2 A to 30 A
 in steps of 4 A

Figure 15. Boost FWD
Typical average static loss as a function of phase displacement


$$P_{loss} = f(\varphi)$$


 Conditions: $T_j = 125 \text{ } ^\circ\text{C}$
 parameter: I_{oRMS} from 2 A to 30 A
 in steps of 4 A

flowNPC1 NPC Application 600V/41mΩ

Figure 16. Boost MOSFET


Typical average switching loss as a function of phase displacement



Conditions: $T_j = 125$ °C $f_{sw} = 50$ kHz
DC link = 700 V
parameter: I_{oRMS} from 2 A to 30 A
in steps of 4 A A

Figure 17. Boost FWD


Typical average switching loss as a function of phase displacement



Conditions: $T_j = 125$ °C $f_{sw} = 50$ kHz
DC link = 700 V
parameter: I_{oRMS} from 2 A to 30 A
in steps of 4 A A

Figure 18. Boost MOSFET


Typical total loss as a function of phase displacement and I_{outRMS}



Conditions: $T_j = 125$ °C
DC link = 700 V
 $f_{sw} = 50$ kHz

Figure 19. Boost FWD

Typical total loss as a function of phase displacement and I_{outRMS}




Conditions: $T_j = 125$ °C
DC link = 700 V
 $f_{sw} = 50$ kHz

flowNPC1 **NPC Application** 600V/41mΩ

Figure 20. Boost MOSFET+FWD


Typical available output current as a function of phase displacement



Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$ $f_{sw} = 50 \text{ kHz}$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 21. Boost MOSFET+FWD


Typical available output current as a function of switching frequency



Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$ $\phi = 90^\circ$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 22. Boost MOSFET+FWD

Typical available 50Hz output current as a function of fsw and phase displacement




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ } ^\circ\text{C}$

flowNPC1 NPC Application 600V/41mΩ

Figure 23. per MODULE


Typical available output current as a function of heat sink temperature



Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
DC link = 700 V
 $\varphi = 0^\circ$
parameter: Switching freq.
fsw from 2 kHz to 128 kHz
in steps of factor 2

Figure 24. per MODULE


Typical available output current as a function of phase displacement



Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
DC link = 700 V
fsw = 50 kHz
parameter: Heatsink temp.
Th from 50 °C to 100 °C
in 10 °C steps

Figure 25. per MODULE


Typical available output current as a function of switching frequency



Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$ $\varphi = 0^\circ$
DC link = 700 V
parameter: Heatsink temp.
Th from 50 °C to 100 °C
in 10 °C steps

Figure 26. per MODULE

Typical available 50Hz output current as a function of fsw and phase displacement



Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
DC link = 700 V
 $T_h = 80 \text{ } ^\circ\text{C}$

flowNPC1


NPC Application

600V/41mΩ

Figure 27. per MODULE

Typical efficiency as a function of output power

$$\eta = f(P_{out})$$




Conditions: $T_j = 125^\circ\text{C}$
 $f_{sw} = 50\text{ kHz}$
 DC link = 700 V
 parameter: phase displacement ϕ from 0° to 180° in steps of 30°

Figure 28. per MODULE

Typical efficiency as a function of output power

$$\eta = f(P_{out})$$




Conditions: $T_j = 125^\circ\text{C}$ $\phi = 0^\circ$
 DC link = 700 V
 parameter: Switching freq. f_{sw} from 2 kHz to 128 kHz in steps of factor 2

Figure 29. per MODULE

Typical available output power as a function of heat sink temperature

$$P_{out} = f(T_h)$$



Conditions: $T_j = T_{jmax} - 25^\circ\text{C}$
 DC link = 700 V
 $\phi = 0^\circ$
 parameter: Switching freq. f_{sw} from 2 kHz to 128 kHz in steps of factor 2

Figure 30. per MODULE

Typical application





Figure 31. per MODULE

Typical loss distribution as a function of output current

$P_{out}=f(T_h)$




Conditions:

$T_j=$	125	°C
$f_{sw}=$	50	kHz
DC link=	700	V
$\varphi=$	0°	

Figure 32. per MODULE

Typical relativ loss distribution as a function of output current

$P_{out}=f(T_h)$



Conditions:

$T_j=$	125	°C
$f_{sw}=$	50	kHz
DC link=	700	V
$\varphi=$	0°	