

General conditions


BUCK		
V_{GEon}	=	+ 15 V
V_{GEoff}	=	- 15 V
R_{gon}	=	4 Ω
R_{goff}	=	4 Ω

$V_{out} = 230 V_{AC}$

BOOST		
V_{GEon}	=	+ 15 V
V_{GEoff}	=	- 15 V
R_{gon}	=	4 Ω
R_{goff}	=	4 Ω

Figure 1. Buck MOSFET+IGBT


Typical average static loss as a function of output current I_{oRMS}



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: ϕ from 0° to 180°
in 12 steps

Figure 2. Buck FWD


Typical average static loss as a function of output current I_{oRMS}



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: ϕ from 0° to 180°
in 12 steps

Figure 3. Buck MOSFET+IGBT


Typical average static loss as a function of phase displacement ϕ



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: I_{oRMS} from 4,24 A to 63 A
in steps of 8 A

Figure 4. Buck FWD


Typical average static loss as a function of phase displacement ϕ



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
parameter: I_{oRMS} from 4,24 A to 63 A
in steps of 8 A

Figure 5. Buck MOSFET+IGBT
Typical average switching loss as a function of phase displacement φ


$$P_{\text{loss}} = f(\varphi)$$



Conditions: $T_j = 125$ °C
 $f_{\text{sw}} = 20$ kHz
 DC link = 700 V
 parameter: I_{ORMS} from 4,24 A to 63 A
 in steps of 8 A

Figure 6. Buck FWD
Typical average switching loss as a function of phase displacement φ


$$P_{\text{loss}} = f(\varphi)$$



Conditions: $T_j = 125$ °C
 $f_{\text{sw}} = 20$ kHz
 DC link = 700 V
 parameter: I_{ORMS} from 4,24 A to 63 A
 in steps of 8 A

Figure 7. Buck MOSFET+IGBT
Typical total loss as a function of phase displacement φ and output current I_{ORMS}


$$P_{\text{loss}} = f(I_{\text{ORMS}}; \varphi)$$



Conditions: $T_j = 125$ °C
 DC link = 700 V
 $f_{\text{sw}} = 20$ kHz

Figure 8. Buck FWD
Typical total loss as a function of phase displacement φ and output current I_{ORMS}

$$P_{\text{loss}} = f(I_{\text{ORMS}}; \varphi)$$




Conditions: $T_j = 125$ °C
 DC link = 700 V
 $f_{\text{sw}} = 20$ kHz

Figure 9. for Buck MOSFET+IGBT+FWD

Typical available output current as a function of phase displacement φ

$$I_{out}=f(\varphi)$$




Conditions: $T_j = T_{jmax}-25 \text{ }^\circ\text{C}$ $f_{sw} = 20 \text{ kHz}$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 10. for Buck MOSFET+IGBT+FWD

Typical available output current as a function of switching frequency f_{sw}

$$I_{out}=f(f_{sw})$$




Conditions: $T_j = T_{jmax}-25 \text{ }^\circ\text{C}$ $\varphi = 0^\circ$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 11. for Buck MOSFET+IGBT+FWD

Typical available 50Hz output current as a function of f_{sw} and phase displacement φ


$$I_{out}=f(f_{sw},\varphi)$$



Conditions: $T_j = T_{jmax}-25 \text{ }^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ }^\circ\text{C}$

Figure 12. Boost IGBT
Typical average static loss as a function of output current


$$P_{\text{loss}} = f(I_{\text{out}})$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 parameter: φ from 0° to 180°
 in 12 steps

Figure 13. Boost FWD
Typical average static loss as a function of output current


$$P_{\text{loss}} = f(I_{\text{out}})$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 parameter: φ from 0° to 180°
 in 12 steps

Figure 14. Boost IGBT
Typical average static loss as a function of phase displacement


$$P_{\text{loss}} = f(\varphi)$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 parameter: I_{ORMS} from 4 A to 63 A
 in steps of 8 A

Figure 15. Boost FWD
Typical average static loss as a function of phase displacement


$$P_{\text{loss}} = f(\varphi)$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 parameter: I_{ORMS} from 4 A to 63 A
 in steps of 8 A

Figure 16. Boost IGBT
Typical average switching loss as a function of phase displacement


$$P_{\text{loss}}=f(\varphi)$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$ $f_{\text{sw}} = 20 \text{ kHz}$
 DC link = 700 V
 parameter: I_{ORMS} from 4 A to 63 A
 in steps of 8 A A

Figure 17. Boost FWD
Typical average switching loss as a function of phase displacement


$$P_{\text{loss}}=f(\varphi)$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$ $f_{\text{sw}} = 20 \text{ kHz}$
 DC link = 700 V
 parameter: I_{ORMS} from 4 A to 63 A
 in steps of 8 A A

Figure 18. Boost IGBT
Typical total loss as a function of phase displacement and I_{outRMS}


$$P_{\text{loss}}=f(I_{\text{ORMS}};\varphi)$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 DC link = 700 V
 $f_{\text{sw}} = 20 \text{ kHz}$

Figure 19. Boost FWD
Typical total loss as a function of phase displacement and I_{outRMS}


$$P_{\text{loss}}=f(I_{\text{ORMS}};\varphi)$$



Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 DC link = 700 V
 $f_{\text{sw}} = 20 \text{ kHz}$

Figure 20. Boost IGBT+FWD
Typical available output current as a function of phase displacement

$$I_{out}=f(\varphi)$$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$ $f_{sw} = 20 \text{ kHz}$
 DC link = 700 V

parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 21. Boost IGBT+FWD
Typical available output current as a function of switching frequency

$$I_{out}=f(f_{sw})$$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$ $\varphi = 90^\circ$
 DC link = 700 V

parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 22. Boost IGBT+FWD
Typical available 50Hz output current as a function of fsw and phase displacement

$$I_{out}=f(f_{sw}, \varphi)$$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ } ^\circ\text{C}$

Figure 23. per MODULE

Typical available output current as a function of heat sink temperature

$$I_{out} = f(T_h)$$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $\varphi = 0^\circ$

parameter: Switching freq.
 fsw from 2 kHz to 128 kHz
 in steps of factor 2

Figure 24. per MODULE

Typical available output current as a function of phase displacement

$$I_{out} = f(\varphi)$$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $f_{sw} = 20 \text{ kHz}$

parameter: Heatsink temp.
 T_h from 50 °C to 100
 in 10 °C steps

Figure 25. per MODULE

Typical available output current as a function of switching frequency

$$I_{out} = f(f_{sw})$$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$ $\varphi = 0^\circ$
 DC link = 700 V

parameter: Heatsink temp.
 T_h from 50 °C to 100
 in 10 °C steps

Figure 26. per MODULE

Typical available 50Hz output current as a function of fsw and phase displacement

$$I_{out} = f(f_{sw}, \varphi)$$




Conditions: $T_j = T_{jmax} - 25 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ } ^\circ\text{C}$

Figure 27. per MODULE

Typical efficiency as a function of output power

$$\eta=f(P_{out})$$




Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 $f_{sw} = 20 \text{ kHz}$
DC link = 700 V

parameter: phase displacement φ from 0° to 180° in steps of 30°

Figure 28. per MODULE

Typical efficiency as a function of output power

$$\eta=f(P_{out})$$




Conditions: $T_j = 125 \text{ }^\circ\text{C}$ $\varphi = 0^\circ$
DC link = 700 V

parameter: Switching freq. f_{sw} from 2 kHz to 128 kHz in steps of factor 2

Figure 29. per MODULE

Typical available output power as a function of heat sink temperature

$$P_{out}=f(T_h)$$




Conditions: $T_j = T_{jmax}-25 \text{ }^\circ\text{C}$
DC link = 700 V
 $\varphi = 0^\circ$

parameter: Switching freq. f_{sw} from 2 kHz to 128 kHz in steps of factor 2

Figure 30. per MODULE

Typical loss distribution as a function of output current

$$P_{out}=f(T_h)$$




Conditions: $T_j = 125 \text{ }^\circ\text{C}$
 $f_{sw} = 20 \text{ kHz}$
DC link = 700 V
 $\varphi = 0^\circ$

Figure 31.

per MODULE

Typical relativ loss distribution as a function of output current

$$P_{out} = f(T_j)$$



Conditions:

$T_j =$	125	°C
$f_{sw} =$	20	kHz
DC link =	700	V
$\phi =$	0°	

Figure 32.

per MODULE

