



flow PIM 0 Inverter Application 600 V / 20 A


General conditions

<b>3phase SPWM</b>	
$V_{GEon}$	= 15 V
$V_{GEoff}$	= 0 V
$R_{gon}$	= 32 $\Omega$
$R_{goff}$	= 16 $\Omega$

Figure 1 IGBT

Typical average static loss as a function of output current

$P_{loss} = f(I_{out})$




At  
 $T_j = 125 \text{ }^\circ\text{C}$   
 $Mi \cdot \cos\phi$  from -1 to 1 in steps of 0,2

Figure 2 FWD

Typical average static loss as a function of output current

$P_{loss} = f(I_{out})$




At  
 $T_j = 125 \text{ }^\circ\text{C}$   
 $Mi \cdot \cos\phi$  from -1 to 1 in steps of 0,2

Figure 3 IGBT

Typical average switching loss as a function of output current

$P_{loss} = f(I_{out})$




At  
 $T_j = 125 \text{ }^\circ\text{C}$   
DC link = 320 V  
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

Figure 4 FWD

Typical average switching loss as a function of output current

$P_{loss} = f(I_{out})$




At  
 $T_j = 125 \text{ }^\circ\text{C}$   
DC link = 320 V  
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2



**flow PIM 0 Inverter Application 600 V / 20 A**

**Figure 5** Phase


Typical available 50Hz output current as a function  $Mi \cdot \cos \varphi$   $I_{out} = f(Mi \cdot \cos \varphi)$



**At**  
 $T_j = 125^\circ C$   
 DC link = 320 V  
 $f_{sw} = 4$  kHz  
 $T_h$  from 60 °C to 100 °C in steps of 5 °C

**Figure 6** Phase


Typical available 50Hz output current as a function of switching frequency  $I_{out} = f(f_{sw})$



**At**  
 $T_j = 125^\circ C$   
 DC link = 320 V  
 $Mi \cdot \cos \varphi = 0,8$   
 $T_h$  from 60 °C to 100 °C in steps of 5 °C

**Figure 7** Phase


Typical available 50Hz output current as a function of  $Mi \cdot \cos \varphi$  and switching frequency  $I_{out} = f(f_{sw}, Mi \cdot \cos \varphi)$



**At**  
 $T_j = 125^\circ C$   
 DC link = 320 V  
 $T_h = 80^\circ C$

**Figure 8** Phase

Typical available 0Hz output current as a function of switching frequency  $I_{outpeak} = f(f_{sw})$




**At**  
 $T_j = 125^\circ C$   
 DC link = 320 V  
 $T_h$  from 60 °C to 100 °C in steps of 5 °C  
 $Mi = 0$



**flow PIM 0 Inverter Application 600 V / 20 A**

**Figure 9** Inverter


**Typical available peak output power as a function of heatsink temperature**  
 $P_{out}=f(T_h)$



**At**  
 $T_j = 125$  °C  
 DC link = 320 V  
 $M_i = 1$   
 $\cos \varphi = 0,80$   
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 10** Inverter


**Typical efficiency as a function of output power**  
 efficiency=f( $P_{out}$ )



**At**  
 $T_j = 125$  °C  
 DC link = 320 V  
 $M_i = 1$   
 $\cos \varphi = 0,80$   
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 11** Inverter

**Typical available overload factor as a function of motor power and switching frequency**  
 $P_{peak} / P_{nom}=f(P_{nom}, f_{sw})$



**At**  
 $T_j = 125$  °C  
 DC link = 320 V  
 $M_i = 1$   
 $\cos \varphi = 0,8$   
 $f_{sw}$  from 1 kHz to 16kHz in steps of factor 2  
 $T_h = 80$  °C  
 Motor eff =0,85