

flowPIM 1 3rd gen

Output Inverter Application

1200V / 35A

General conditions**3phase SPWM**


$V_{G\text{Eon}}$	= 15 V
$V_{G\text{Eoff}}$	= -15 V
$R_{g\text{on}}$	= 16 Ω
$R_{g\text{off}}$	= 16 Ω

Figure 1

IGBT

Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$


Mi*cosφ from -1 to 1 in steps of 0.2

Figure 2

FRED

Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$


Mi*cosφ from -1 to 1 in steps of 0.2

Figure 3

IGBT

Typical average switching loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$


$$\text{DC link} = 600 \text{ V}$$

f_{sw} from 2 kHz to 16 kHz in steps of factor 2**Figure 4**

FRED

Typical average switching loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC link} = 600 \text{ V}$$

f_{sw} from 2 kHz to 16 kHz in steps of factor 2


flowPIM 1 3rd gen

Output Inverter Application

1200V / 35A

Figure 5


**Typical available 50Hz output current
as a function $M_i \cos \varphi$**

**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $f_{sw} = 8 \text{ kHz}$
 T_h from $60 \text{ } ^\circ\text{C}$ to $100 \text{ } ^\circ\text{C}$ in steps of $5 \text{ } ^\circ\text{C}$

Figure 7


**Typical available 50Hz output current as a function of
 $M_i \cos \varphi$ and switching frequency**

**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $T_h = 90 \text{ } ^\circ\text{C}$

Figure 6


**Typical available 50Hz output current
as a function of switching frequency**

**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $M_i \cos \varphi = 0.8$
 T_h from $60 \text{ } ^\circ\text{C}$ to $100 \text{ } ^\circ\text{C}$ in steps of $5 \text{ } ^\circ\text{C}$

Figure 8

**Typical available 0Hz output current as a function
of switching frequency**


**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 T_h from $60 \text{ } ^\circ\text{C}$ to $100 \text{ } ^\circ\text{C}$ in steps of $5 \text{ } ^\circ\text{C}$
 $M_i = 0$


flowPIM 1 3rd gen

Output Inverter Application


1200V / 35A

Figure 9**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $M_i = 1$
 $\cos \varphi = 0.80$
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

Figure 10**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $M_i = 1$
 $\cos \varphi = 0.80$
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

Figure 11**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $M_i = 1$
 $\cos \varphi = 0.8$
 f_{sw} from 1 kHz to 16 kHz in steps of factor 2
 $T_h = 90 \text{ } ^\circ\text{C}$
 Motor eff = 0.85