

**General conditions**
**3phase SPWM**

$V_{GEon} = 15 \text{ V}$


$V_{GEoff} = -15 \text{ V}$

$R_{gon} = 8 \ \Omega$

$R_{goff} = 8 \ \Omega$

**Figure 1**
**IGBT**
**Typical average static loss as a function of output current**

$P_{loss} = f(I_{out})$



**At**

$T_j = 125 \text{ }^\circ\text{C}$

 $M_i \cdot \cos\phi$  from -1 to 1 in steps of 0,2

**Figure 2**
**FWD**
**Typical average static loss as a function of output current**

$P_{loss} = f(I_{out})$



**At**

$T_j = 125 \text{ }^\circ\text{C}$

 $M_i \cdot \cos\phi$  from -1 to 1 in steps of 0,2

**Figure 3**
**IGBT**
**Typical average switching loss as a function of output current**

$P_{loss} = f(I_{out})$


**At**


$T_j = 125 \text{ }^\circ\text{C}$

DC link = 320 V

 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 4**
**FWD**
**Typical average switching loss as a function of output current**

$P_{loss} = f(I_{out})$


**At**


$T_j = 125 \text{ }^\circ\text{C}$

DC link = 320 V

 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 5** Phase


Typical available 50Hz output current as a function  $Mi \cdot \cos \varphi$   $I_{out} = f(Mi \cdot \cos \varphi)$



**At**  
 $T_j = 125 \text{ } ^\circ\text{C}$   
 DC link = 320 V  
 $f_{sw} = 4 \text{ kHz}$   
 $T_h$  from 60 °C to 100 °C in steps of 5 °C

**Figure 6** Phase


Typical available 50Hz output current as a function of switching frequency  $I_{out} = f(f_{sw})$



**At**  
 $T_j = 125 \text{ } ^\circ\text{C}$   
 DC link = 320 V  
 $Mi \cdot \cos \varphi = 0,8$   
 $T_h$  from 60 °C to 100 °C in steps of 5 °C

**Figure 7** Phase


Typical available 50Hz output current as a function of  $Mi \cdot \cos \varphi$  and switching frequency  $I_{out} = f(f_{sw}, Mi \cdot \cos \varphi)$



**At**  
 $T_j = 125 \text{ } ^\circ\text{C}$   
 DC link = 320 V  
 $T_h = 80 \text{ } ^\circ\text{C}$


**Figure 8** Phase

Typical available 0Hz output current as a function of switching frequency  $I_{outpeak} = f(f_{sw})$




**At**  
 $T_j = 125 \text{ } ^\circ\text{C}$   
 DC link = 320 V  
 $T_h$  from 60 °C to 100 °C in steps of 5 °C  
 $Mi = 0$


**Figure 9** Inverter

**Typical available peak output power as a function of heatsink temperature**  
 $P_{out}=f(T_h)$ 

**At**  
 $T_j = 125 \text{ } ^\circ\text{C}$   
 DC link = 320 V  
 $M_i = 1$   
 $\cos \varphi = 0,80$   
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 10** Inverter

**Typical efficiency as a function of output power**  
 $\text{efficiency}=f(P_{out})$ 

**At**  
 $T_j = 125 \text{ } ^\circ\text{C}$   
 DC link = 320 V  
 $M_i = 1$   
 $\cos \varphi = 0,80$   
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 11** Inverter

**Typical available overload factor as a function of motor power and switching frequency**  
 $P_{peak} / P_{nom}=f(P_{nom}, f_{sw})$ 

**At**  
 $T_j = 125 \text{ } ^\circ\text{C}$   
 DC link = 320 V  
 $M_i = 1$   
 $\cos \varphi = 0,8$   
 $f_{sw}$  from 1 kHz to 16kHz in steps of factor 2  
 $T_h = 80 \text{ } ^\circ\text{C}$   
 Motor eff = 0,85