

flowBOOST 0**DC Boost Application**

1200V/40A


General conditions

BOOST	
V_{GEon}	= 15 V
V_{GOff}	= 0 V
R_{gon}	= 4 Ω
R_{goff}	= 4 Ω

Figure 1.

Typical average static loss as a function of input current I_{in} RMS

$$P_{loss} = f(I_{in})$$



Conditions: $T_j = 125^\circ C$


Ratio of input DC voltage to output DC voltage

parameter: V_{in}/V_{out} from 0,2 to 1,0
in 0,2 steps

Figure 3.

Typical average switching loss as a function of input current

$$P_{loss} = f(I_{in})$$




Conditions: $T_j = 125^\circ C$
 $V_{out} = 700 V$

Sw. freq. fsw from 4 kHz to 32 kHz
in steps of factor 2

Figure 2.

Typical average static loss as a function of input current I_{in} RMS

$$P_{loss} = f(I_{in})$$



Conditions: $T_j = 125^\circ C$


Ratio of input DC voltage to output DC voltage

parameter: V_{in}/V_{out} from 0,2 to 1,0
in 0,2 steps

Figure 4.


Typical average switching loss as a function of input current

$$P_{loss} = f(I_{in})$$




Conditions: $T_j = 125^\circ C$
 $V_{out} = 700 V$


Sw. freq. fsw from 4 kHz to 32 kHz
in steps of factor 2

flowBOOST 0
DC Boost Application
1200V/40A



Conditions: $T_j = T_{jmax}-25^\circ C$
 DC link= 700 V $f_{sw}= 16$ kHz
 parameter: Heatsink temp.
 Th from 60 °C to 100 °C
 in 10 °C steps



Conditions: $T_j = T_{jmax}-25^\circ C$
 DC link= 700 V $V_{in} = 500$ V
 parameter: Heatsink temp.
 Th from 60 °C to 100 °C
 in 10 °C steps




Conditions: $T_j = T_{jmax}-25^\circ C$
 DC link= 700 V $Th = 80$ °C



Conditions: $T_j = T_{jmax}-25^\circ C$
 $V_{in} = 500$ V $DC \text{ link=} 700$ V
 Sw. freq. f_{sw} from 4 kHz to 32 kHz

flowBOOST 0
DC Boost Application
1200V/40A
Figure 9.
per PHASE
**Typical efficiency as a function of
input power**

$$\eta=f(P_{in})$$


Conditions: T_j = T_{jmax}-25°C

Vin 500 V DC link= 700 V

parameter:

Sw. freq. fsw from 4 kHz to 32 kHz