

flow90PIM 1

Output Inverter Application


1200V/4A

General conditions**3phase SPWM**

V_{GEon}	= 15 V
V_{GOff}	= -15 V
R_{gon}	= 64 Ω
R_{goff}	= 64 Ω

Figure 1**Typical average static loss as a function of output current**

$$P_{loss} = f(I_{out})$$


**At**

$$T_j = 150 \quad ^\circ\text{C}$$

Mi*cosφ from -1 to 1 in steps of 0,2

IGBT**Figure 2****Typical average static loss as a function of output current**

$$P_{loss} = f(I_{out})$$


**At**

$$T_j = 150 \quad ^\circ\text{C}$$

Mi*cosφ from -1 to 1 in steps of 0,2

Figure 3**Typical average switching loss as a function of output current**

$$P_{loss} = f(I_{out})$$


**At**

$$T_j = 150 \quad ^\circ\text{C}$$

$$\text{DC link} = 600 \quad \text{V}$$

f_{sw} from 2 kHz to 16 kHz in steps of factor 2**IGBT****Figure 4****Typical average switching loss as a function of output current**

$$P_{loss} = f(I_{out})$$

**At**

$$T_j = 150 \quad ^\circ\text{C}$$

$$\text{DC link} = 600 \quad \text{V}$$

f_{sw} from 2 kHz to 16 kHz in steps of factor 2


flow90PIM 1

Output Inverter Application

1200V/4A

Figure 5


**Typical available 50Hz output current
as a function $M_i \cos \phi$**

**At**

$T_j = 150 \quad ^\circ C$
 DC link = 600 V
 $f_{sw} = 4 \quad kHz$
 T_h from $60^\circ C$ to $100^\circ C$ in steps of $5^\circ C$

Phase**Figure 6**


**Typical available 50Hz output current
as a function of switching frequency**

**At**

$T_j = 150 \quad ^\circ C$
 DC link = 600 V
 $M_i \cos \phi = 0.8$
 T_h from $60^\circ C$ to $100^\circ C$ in steps of $5^\circ C$

Figure 7


**Typical available 50Hz output current as a function of
 $M_i \cos \phi$ and switching frequency**

**At**

$T_j = 150 \quad ^\circ C$
 DC link = 600 V
 $T_h = 80 \quad ^\circ C$

Phase**Figure 8**

**Typical available 0Hz output current as a function
of switching frequency**


**At**

$T_j = 150 \quad ^\circ C$
 DC link = 600 V
 T_h from $60^\circ C$ to $100^\circ C$ in steps of $5^\circ C$
 $M_i = 0$


flow90PIM 1

Output Inverter Application


1200V/4A

Figure 9**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $M_i = 1$
 $\cos \varphi = 0,80$
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

Figure 10**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $M_i = 1$
 $\cos \varphi = 0,80$
 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

Figure 11**At**

$T_j = 150 \text{ } ^\circ\text{C}$
 DC link = 600 V
 $M_i = 1$
 $\cos \varphi = 0,8$
 f_{sw} from 1 kHz to 16 kHz in steps of factor 2
 $T_h = 80 \text{ } ^\circ\text{C}$
 Motor eff = 0,85