


Output Inverter Application

1200 V / 50 A
General conditions

3phase SPWM	
$V_{G\text{Eon}}$	= 15 V
$V_{G\text{Eoff}}$	= -15 V
$R_{g\text{on}}$	= 8 Ω
$R_{g\text{off}}$	= 8 Ω

Figure 1
IGBT
Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$



At

$$T_j = 150 \text{ } ^\circ\text{C}$$

Mi*cosfi from -1 to 1 in steps of 0,2

Figure 2
FWD
Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$



At

$$T_j = 150 \text{ } ^\circ\text{C}$$

Mi*cosfi from -1 to 1 in steps of 0,2

Figure 3
IGBT
Typical average switching loss
as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$


At


$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC link} = 600 \text{ V}$$

fsw from 2 kHz to 16 kHz in steps of factor 2

Figure 4
FWD
Typical average switching loss
as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$


At

$$T_j = 150 \text{ } ^\circ\text{C}$$


$$\text{DC link} = 600 \text{ V}$$

fsw from 2 kHz to 16 kHz in steps of factor 2


Output Inverter Application

1200 V / 50 A
Figure 5

**Typical available 50Hz output current
as a function $M_i \cdot \cos f_i$**



At
 $T_j = 150 \text{ } ^\circ\text{C}$
 $\text{DC link} = 600 \text{ V}$
 $f_{sw} = 4 \text{ kHz}$
 $\text{Th from } 60 \text{ } ^\circ\text{C to } 100 \text{ } ^\circ\text{C in steps of } 5 \text{ } ^\circ\text{C}$
Phase
Figure 6

**Typical available 50Hz output current
as a function of switching frequency**


At
 $T_j = 150 \text{ } ^\circ\text{C}$
 $\text{DC link} = 600 \text{ V}$
 $M_i \cdot \cos f_i = 0,8$
 $\text{Th from } 60 \text{ } ^\circ\text{C to } 100 \text{ } ^\circ\text{C in steps of } 5 \text{ } ^\circ\text{C}$
Figure 7

Typical available 50Hz output current as a function of

$M_i \cdot \cos f_i$ and switching frequency


At
 $T_j = 150 \text{ } ^\circ\text{C}$
 $\text{DC link} = 600 \text{ V}$
 $T_h = 80 \text{ } ^\circ\text{C}$
Phase
Figure 8

**Typical available 0Hz output current as a function
of switching frequency**

$I_{outpeak} = f(f_{sw})$




At
 $T_j = 150 \text{ } ^\circ\text{C}$
 $\text{DC link} = 600 \text{ V}$
 $\text{Th from } 60 \text{ } ^\circ\text{C to } 100 \text{ } ^\circ\text{C in steps of } 5 \text{ } ^\circ\text{C}$

Figure 9
Inverter
Typical available peak output power as a function of heatsink temperature

$$P_{out} = f(T_h)$$


At

T_j = 150 °C

DC link = 600 V


Mi = 1

cosfi = 0,80

fsw from 2 kHz to 16 kHz in steps of factor 2

Figure 10
Inverter
Typical efficiency as a function of output power

$$\text{efficiency} = f(P_{out})$$


At

T_j = 150 °C

DC link = 600 V


Mi = 1

cosfi = 0,80

fsw from 2 kHz to 16 kHz in steps of factor 2

Figure 11
Inverter
Typical available overload factor as a function of motor power and switching frequency

$$P_{peak} / P_{nom} = f(P_{nom}, f_{sw})$$


At

T_j = 150 °C

DC link = 600 V

Mi = 1

cosfi = 0,8

fsw from 1 kHz to 16 kHz in 2 steps

Th = 80 °C

Motor eff = 0,85