

flowPACK 1 3rd gen
Inverter Application
1200 V / 75 A
General conditions
3phase SPWM

$$V_{G\text{on}} = 15 \text{ V}$$

$$V_{G\text{off}} = -15 \text{ V}$$

$$R_{\text{gon}} = 4 \Omega$$


$$R_{\text{goff}} = 4 \Omega$$

Figure 1

IGBT

Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$


At

$$T_j = 150 \text{ } ^\circ\text{C}$$


Mi*cosfi from -1 to 1 in steps of 0,2

Figure 2

FWD

Typical average static loss as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$


At

$$T_j = 150 \text{ } ^\circ\text{C}$$


Mi*cosfi from -1 to 1 in steps of 0,2

Figure 3

IGBT

Typical average switching loss
as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$


At

$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC-link} = 600 \text{ V}$$


f_{sw} from 2 kHz to 16 kHz in steps of factor 2

Figure 4

FWD

Typical average switching loss
as a function of output current

$$P_{\text{loss}} = f(I_{\text{out}})$$


At

$$T_j = 150 \text{ } ^\circ\text{C}$$


$$\text{DC-link} = 600 \text{ V}$$

f_{sw} from 2 kHz to 16 kHz in steps of factor 2

Figure 5

Typical available 50Hz output current as a function $M_i \cdot \cos fi$

$$I_{out} = f(M_i \cdot \cos fi)$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC-link} = 600 \text{ V}$$


$$f_{sw} = 4 \text{ kHz}$$

T_s from 60 °C to 100 °C in steps of 5 °C

Phase**Figure 6**

Typical available 50Hz output current as a function of switching frequency $I_{out} = f(f_{sw})$

$$I_{out} = f(f_{sw})$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$


$$\text{DC-link} = 600 \text{ V}$$

$$Mi \cdot \cos fi = 0,8$$

T_s from 60 °C to 100 °C in steps of 5 °C

Figure 7

Typical available 50Hz output current as a function of $Mi \cdot \cos fi$ and switching frequency $I_{out} = f(f_{sw}, Mi \cdot \cos fi)$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$


$$\text{DC-link} = 600 \text{ V}$$

$$T_s = 80 \text{ } ^\circ\text{C}$$

Figure 8

Typical available 0Hz output current as a function of switching frequency $I_{outpeak} = f(f_{sw})$

$$I_{outpeak} = f(f_{sw})$$

**At**

$$T_j = 150 \text{ } ^\circ\text{C}$$

$$\text{DC-link} = 600 \text{ V}$$

T_s from 60 °C to 100 °C in steps of 5 °C

$$Mi = 0$$



Vincotech

flow PACK 1 3rd gen

Inverter Application


V23990-P820-F10-PM

V23990-P820-F10Y-PM

1200 V / 75 A

Figure 9

Inverter

Typical available peak output power as a function of heatsink temperature
 $P_{out}=f(T_s)$ 

At

 $T_j = 150 \text{ } ^\circ\text{C}$

DC-link = 600 V


Mi = 1

cosfi = 0,80

 f_{sw} from 60 °C to 100 °C in steps of 5 °C

Figure 10

Inverter

Typical efficiency as a function of output power
efficiency=f(P_{out})

At

 $T_j = 150 \text{ } ^\circ\text{C}$

DC-link = 600 V


Mi = 1

cosfi = 0,80

 f_{sw} from 2 kHz to 16 kHz in steps of factor 2

Figure 11

Inverter

Typical available overload factor as a function of motor power and switching frequency $P_{peak} / P_{nom} = f(P_{nom}, f_{sw})$ 

At

 $T_j = 150 \text{ } ^\circ\text{C}$

DC-link = 600 V

Mi = 1

cosfi = 0,8

 f_{sw} from 1 kHz to 16 kHz in steps of factor 2 $T_s = 90 \text{ } ^\circ\text{C}$

Motor eff = 0,85